

Codification MOVITRAC® LTE-B & MOVITRAC® LTP-B

SEW
USOCOME



MOVITRAC® LTE-B

Exemple de codification

Made in the UK

Serial No.: 06259169713001



MCLTEB0015-2B1-4-00

SEW Part No: 18261892



S/Ware : 2.00

Risk of Electric Shock

Power down for 5min before removing cover



CAUTION

SCCR: Refer to User Guide for rating and protection

IP 20 Indoor Use Only

	Input	Output
V	200-240	0-250
Ø	1	3
F (Hz)	50/60	0-500
I (A)	13	7.0
kW	1.5	
HP	2	

www.sew-eurodrive.com



UL

Liste d2AD0 ind. Conv. Eq. E155763

Plaque signalétique MOVITRAC® LTE-B

Exemple : MCLTE-1-B 0015-201-1-00		
Nom du produit	MCLTE	MOVITRAC® LTE-B
Version	B	Version de la gamme d'appareils
Moteur	1	Uniquement moteurs monophasés
Puissance moteur utile	0015	0015 = 1.5 kW
Tension de raccordement	2	1 = 115 V 2 = 200 – 240 V 5 = 380 – 480 V
Antiparasitage à l'entrée	0	0 = classe 0 - A = C2 (classe A) - B = C1 (classe B)
Mode de branchement	1	1 = monophasé 3 = triphasé
Quadrants	1	1 = fonctionnement 1 quadrant sans frein-hacheur 4 = fonctionnement 4 quadrants avec frein-hacheur
Exécution	00	00 = boîtier IP20 standard 30 = boîtier IP66 / NEMA 4X sans interrupteur 40 = boîtier IP66 / NEMA 4X avec interrupteur



MOVITRAC® LTP-B

Exemple de codification

Made in the UK
Serial No.: 081111111111111


MCLTPB00405A3400
SEW Part No: 18251803
S/Ware : 1.21
Risk of Electric Shock
Power down for 5min before removing cover

CAUTION
SCCR: Refer to User Guide for rating and protection
IP20 Indoor Use Only
www.sew-eurodrive.com

UL
Listed 2AD0
Ind. Conv. Eq.
E155763

	Input	Output
V	380-480	0-500
Ø	3	3
F(Hz)	50/60	0-500
I (A)	11	9.5
kW	4	
HP	5	

Plaque signalétique MOVITRAC® LTP-B

Exemple : MC LTP-B 0015-2B1-4-00 (60 Hz)		
Nom du produit	MCLTP	MOVITRAC® LTP B
Version	B	Version de la gamme d'appareils
Puissance moteur recommandée	0015	0015 = 1.5 kW
Tension de raccordement	2	2 = 200 – 240 V 5 = 380 – 480 V 6 = 500 – 600 V
Antiparasitage à l'entrée	B	0 = appareil sans filtre (pas d'antiparasitage) A = classe C2 B = classe C1
Mode de raccordement	1	1 = monophasé 3 = triphasé
Quadrants	4	4 = fonctionnement 4 quadrants
Exécution	00	00 = boîtier IP20 standard 10 = boîtier IP66/NEMA 4X 10 = boîtier IP55/NEMA 12K 15 = boîtier IP55/NEMA 12K / IP66/NEMA 4X pour l'exploitation sur des réseaux IT 40 = boîtier IP66/NEMA 4X avec interrupteur xH = version hautes fréquences